

### Standard Packages

Unit Width	Active Panel Width	Inactive* Panel Width	Swing Opening	Rough Opening Width
5'-3 1/2" (1613)	3'-0" (914)	2'-0" (610)	4'-5 5/8" (1362)	5'-4" (1626)
5'-9 1/2" (1765)	3'-6" (1067)	2'-0" (610)	4'-11 5/8" (1514)	5'-10" (1778)
6'-3 1/2" (1918)	4'-0" (1219)	2'-0" (610)	5'-5 5/8" (1667)	6'-4" (1930)

**Unit Height:** 7'-2 1/2" (2197)  
**Rough Opening Height:** 7'-2 3/4" (2203)  
**Glazing:** Prep for nominal 9/16" (14) glazing  
**\*Optional Inactive Panel Width:** Up to 4'-0" (1219)

**Anodized Finish:**  
Clear or Dark Bronze

### Compliant with:

- **STC-35 Sound Transmission Class Rating**  
In accordance with ASTM E413-04 Classification for Rating Sound Insulation.
- **ASTM E90-04 Standard Test**  
for Laboratory Measurement of Airborne Sound Transmission of Building Partitions and Elements
- **UL 1784 Air Leakage Test of Door Assemblies**
- **NFPA 105 Standard for Installation of Smoke Door Assemblies**

### Installation and Operation

- Door perimeter mounted within curtainwall or rough opening with 1/4" minimum shim space at header & jambs. Finish floor not to exceed 1/4" out of level. Opening to be level & plumb in both directions.
- Active panel (main egress wide panel) can swing open 90° after positive latch is released. Inactive panel (auxiliary egress) can swing open after flush bolt is released. Panels require max. 30 lbs of force applied at the strike stile to open.
- Door panel rises 5/16" on opening 90°. Allow for 1 1/2" ceiling clearance on Swing Side

